

Familiarization with Basic Procedures During Flood Activity

FLOOD ACTIVITY LEVELS FOR THE USE OF THE PREMISES

Flood Activity Level (FAL)	Chuchle		Na Františku	
	Water Gauge Level (cm)	Flow Rate Q (m ³ /s)	Water Gauge Level (cm)	Flow Rate Q (m ³ /s)
FAL – Alertness	140	450	321	455
FAL – Readiness	243	1000	392	1010
FAL – Threat	323	1500	450	1520
Average Annual Water Level H at Chuchle Profile (03 2019) cm	74,0	143	-	-
Average Annual Water Level H at Na Františku Profile (03 2019) cm			Not specified	143

- Flood activity levels are declared by the head of the flood response team or a person authorized by them.
- The declaration is based on available information on rising flow trends from the Crisis Management Operations Center of the City of Prague, the Czech Hydrometeorological Institute (ČHMÚ), and Povodí Vltavy, state enterprise (www.chmi.cz, www.pvl.cz).
- The declaration must be recorded in the flood log.
- In the event of flood risk, important property (electronics, documents, valuables) must be relocated outside the flood zone to the 2nd above-ground floor.
- In case of imminent flooding, access bollards are permanently lowered to ensure rapid vehicle exit towards V Podbabě Street in the direction of Lysolajské Valley.
- Floating objects and substances that could endanger water quality, as well as equipment and vehicles, must be removed from the floodplain.